

Key registration procedures (Ford, Mazda)

Conventional key type

1. Turn on ignition (position II).
2. Plug the *device* into OBDII socket; it will beep once.
3. Few seconds later you will hear long beep and LED will light continually. It means the procedure have been completed successfully.
4. Turn off ignition and take out the key.

Advanced key type (without hands-free function)

1. Separate a key on two parts.
2. Press 'Start engine' button (if exist).
3. Insert the key into ignition lock socket and turn into position II.
4. Plug the *device* into OBDII socket.
5. Few seconds later you will hear long beep and LED will light continually. It means the procedure have been completed successfully.
6. Turn off ignition and unplug the *device*.

Keyless-Go type

1. Insert new key (that have NOT been registered in any other car) into slot on steering column.
2. Plug the *device* into OBDII socket.
3. Wait for 10 – 15 seconds until you hear short beep.
4. Take out the key from slot within 15 seconds after beep and hold 'Open' button on key for 1-2 seconds.
5. If you hear one short beep, please, repeat step 4. Long beep means the key is successfully registered.

Several short beeps and red light on LED-indicator means error occurred during registration procedure.

It is strongly recommended to use original Ford and Mazda keys or Texas Crypto transponders. You can use keys multiple times on different cars, but you have to erase registered keys on one specific car by means of diagnostic equipment before using the key on another.

Supported model range

Model name	Model code (model year)
Conventional key type	
Focus	C170*, C170_SA*, C307, C307_SA, C307_AP
C-MAX	C214
Fiesta	B256*, B376_AP*
Fiesta S.A.	BV256*
Fiesta	B299 (2008+)
Ikon	B376_AP*
Fusion	CD338, B226*
Fusion	B232 (2008+)
Galaxy	CD340
S-Max	CD340
Mondeo	CD345
Transit	TRANSIT (2006+)
Transit Connect	V227
Tourneo Connect	V227
Mazda3	MAZDA_3 (2006+), J68 (2008+)
Mazda6	J61 (2006+)
Mazda CX-7	J31 (2006+)
Advanced key type	
Mazda 3	MAZDA_3 (2006+), J68 (2008+)
Mazda 6	J61 (2006+)
Mazda CX-7	J31 (2006+)
Keyless-Go type	
Fiesta	B299 (2008+)
Fusion	B232 (2008+)
Mondeo	CD345 (2007+)
Galaxy	CD340 (2008+)
S-Max	CD340 (2008+)